

Model	Power	Rated discharge	Rated lift	Caliber	Starting voltage	Vacuuming
	(w)	(m <sup>3</sup> /h)	(m)	(In)	(kgf/cm <sup>2</sup> )	(m)
WZB-200(A)	200	0.8	12	1	1.0	8
WZB-300(A)	300	1	14	1	1.2	8
WZB-400(A)	400	1.2	15	1	1.6	8
WZB-600(A)	600	1.5	20	1	2.2	8
WZB-800(A)	800	1.8	25	1	2.5	8
WZB-1100(A)	1100	3	30	1.5	2.6	8
WZB-1500(A)	1500	3	35	1.5	3	8

01/

## PRESSURE SENSOR 压力传感器

Induction of the pressure of the water flow in the pump  
感应泵中水流的压力

•  
SHOW  
DETAILS



02/

## PRESSURE SWITCH 自动压力开关

Control the start and stop of the pump

控制泵的启动和停止

•  
SHOW  
DETAILS

03/

## PRESSURE TANK 压力储气罐

Balance the water volume and pressure in the pump  
平衡泵中的水量和压力

•  
SHOW  
DETAILS



04/

## FAN COVER 风扇罩

Better heat dissipation and more durable

更好的散热和更耐用

•  
SHOW  
DETAILS